

# Operating Instructions

  
Yacare



 **Bluestreak**equipment  
The world's best magnetic cleaning equipment

Bluestreak Equipment  
1645 Hwy #3, Delhi  
Ontario, Canada  
N4B2W6

# Yacare Operating Instructions



## STEP 1

### CONNECT SWEEPER

Connect the Yacare magnetic sweeper to the tow vehicle with the 2" ball coupler and safety chains.

You must use a 2" trailer ball, unless you purchased an optional Pintle Ring.



## STEP 2

### KEEP THE TONGUE LEVEL

Try to keep the tongue level with the ground when connecting the magnetic sweeper to the vehicle.

The tongue of the magnetic sweeper should be as level as possible. It can be adjusted by changing the position of the coupler on the trailer tongue or the ball mount on the tow vehicle.





**STEP 3****ADJUST SWEEPING HEIGHT**

Adjust the magnetic sweeping height (distance from ground to bottom of sweeper) to be between 2" and 6".

The lower the magnet, the better, but make sure the magnet is not constantly hitting the ground.

**STEP 4****COLLECT DEBRIS**

Drive the tow vehicle around towing the Yacare magnetic sweeper and collect metal debris.





**STEP 5****CLEAN OFF DEBRIS**

Clean the metal debris off of the Yacare magnetic sweeper by first stopping the tow vehicle.

Push down on one of the Spring Assisted Debris Release Handles until the handle stays in the down position.

The metal debris will release from the magnet and drop to the ground under the magnetic sweeper.

**STEP 6****MOVE SWEEPER FORWARD**

Pull the magnetic sweeper forward with the tow vehicle to expose the metal debris that dropped from the magnet.





**STEP 7****RETURN DEBRIS RELEASE HANDLES TO UPRIGHT POSITION**

Return the Spring Assisted Debris Release Handles to the upright position and continue to pick up metal debris.

## Yacare Parts

All parts are available for the Yacare magnetic sweeper from your dealer or directly from Bluestreak Equipment at:  
[www.bluestreakequipment.com](http://www.bluestreakequipment.com)

## Yacare Video Resources

All Yacare Operating Instructions are available in video format online at [www.bluestreakequipment.com](http://www.bluestreakequipment.com)



